



FONDation pour le
DEveloppement de la
REcherche
PHARMaceutique

Système de management de la qualité
Certifié ISO 9001

Toulouse, December 2nd 2016

STUDY 16-2074

Determination of bactericidal, fungicidal, sporicidal, mycobactericidal and virucidal activity for aerial surface disinfection processes
According to the method described
in the standard NF T 72-281 (November 2014)

Human Health

Additional Conditions : *Clostridium difficile* (spore)

Promotor

OXY'PHARM
917 rue Marcel Paul
94500 CHAMPIGNY SUR MARNE

Test laboratory

FONDEREPHAR
Faculté des Sciences Pharmaceutiques
35 Chemin des Maraîchers
31062 TOULOUSE cedex 9

Dr Catherine FEUILLOLAY
Study Manager

Dr Jocelyne BACARIA
Quality Manager

1. Test Laboratory

FONDEREPHAR

Faculté des Sciences Pharmaceutiques, 35 chemin des Maraîchers 31062 Toulouse cedex 9, France

2. Identification of the aerial disinfection system

Appartus : NOCOSPRAY

Serial number : 37S347

Disinfectant : NOCOLYSE® 6% Neutral

Batch : 031116N (Expiry date: 11/2018)

Concentration of product in the room : 5 ml/m³

One treatment with one hour of wait (carriers recovery after waiting)

Amount of disinfectant diffusion ≈ 160 mL/treatment

Promotor : OXY'PHARM

Storage conditions: Ambient temperature

Period of testing: November 2016

Actives Substances: Hydrogen peroxide


3. Experimental Conditions

a. Tests micro-organisms

- Sporicidal activity :
 - o *Clostridium difficile* (spore) NCTC 13366


The test surface is a cloth material (photo below). The color is unbleached. Some circles (diameter 3,5 cm) were cut, then sterilized in the autoclave (121°C - 15 to 20 minutes).

The cloth material was transferred by OXY'PHARM.



b. Conditions of aerial disinfection system use

- Room :



Relative humidity ranging from 52% to 65%.

Initial temperatures ranging from 20,1°C to 20,5°C.

Test room volume : 32m³.

Distance between the appartus and the carriers : 2,6m (tableau B.1).

Samples were placed for a height between 1m and 1,5m, in a vertical position, with facing away from the source

Diluants and culture media

Interfering substances

1/20 reconstituted milk (Internal preparation - Batch 6927 Exp. Dec/21/2016)

Diluants

Suspension preparation : EPPI (Cooper, Batch 19KB14GA Exp. January 2019)

Recovery solution (Internal preparation - Batch 6915 Exp. Dec/14/2016)

Filtration membranes

Nitrocellulos emembranes 0,45µm (Millipore, batch F6JA76997 Exp. July 2018)

Culture media

Medium for *Clostridium difficile* (Internal preparation - Batch 6916 Exp. Dec/14/2016)

4. Assays

- Treatment 5 mL / m³ - waiting 1H

Tests microorganisms	N Test suspension (CFU/mL)	Preliminary assay			T Control (CFU/spot - 50µL)	n'1 + n'2 UFC/ spot 50µL (dilution/filtration - disc in agar)	Log reduction - Mean
		n1/N1	n2/N2	n3/N1			
<i>C. difficile</i>	2.10 ⁵ - 5.10 ⁵	n1 > 0.5 N1	n2 > 0.5 N2	n3 > 0.5 N1	≈ 10 ⁴		
Date Nov/22/2016		d1 : 125/137	d1 : 90/102	d1 : 105/137	d1 : 9,8.10 ³	d1 : 0 + 0	R1 : 4,03
B: 20,1°C/RH 52%	2,9.10 ⁵	d2 : 127/137	d2 : 83/102	d2 : 92/137	d2 : 1,18.10 ⁴	d2 : 0 + 0	R2 : 4,03
E: 20,5°C/RH 65%					T = 1,07.10 ⁴	d3 : 0 + 0	R3 : 4,03 R = 4,03

T: counting of micro-organisms on the discs.

N₁: counting of test suspension by pour plate technique - N₂: counting of test suspension by filtration method

n₁: counting to search inhibitor effect in agar medium - n₂: counting to search inhibitor effect on membrane filtration - n₃: counting to search inhibitor effect after inclusion of disc in agar medium

n'1: number of survival micro-organisms in 100mL of tryptone-salt - n'2: number of micro-organisms after inclusion of the carrier surface in agar medium.

n'1 + n'2: total number of survival micro-organisms on the carrier surface.

d1: disc N°1 / d2: disc N°2 / d3: disc N°3

FONDEREPHAR

Faculté des Sciences Pharmaceutiques - 35 Chemin des Maraîchers - 31062 TOULOUSE Cedex 09
Tél. 05 62 25 68 60 Fax. 05 61 25 95 72 Email. contact@fonderephar.com

5. Conclusion

According to standard NF T 72-281 (November 2014) and for the test conditions, the couple NOCOSPRAY (serial number 37S347) / NOCOLYSE® 6% Neutral (Batch 031116N Expiry date: November 2018), in use of human health, on the cloth material transfer by client, led to:

- A sporicidal activity (log reduction ≥ 3)
 - After 5 mL/m³ treatment - 1 hour of wait on the following strain :
 - *Clostridium difficile* (spore) NCTC 13366